

Installing the battery pack

CAUTION


Make sure that the inverter AC and DC disconnects are turned off before connecting the power cable to the battery pack.



1. Fix the lift handles to the hex-socket screws on the rear (marked position) of both left and right sides.



2. Mount the wall bracket to a wall. Tighten the screws, ensuring that they are horizontally driven into the wall. (Must be installed with recommended clearances(720mm[29"]) on the edge of the wall bracket as shown in the figure)



3. Mount the battery pack to a wall bracket's "U" shape clip using the support by lift handles. Remove the lift handles.